

Scanner Model	Group	Scanner Model	Group
<b>Agfa ADMIS S 61</b>	G	<b>Canon DR-2010C</b>	A
		Canon DR-2050C	A
<b>Avision AV220C2/D2+</b>	A	Canon DR-2080C	A
Avision AD230	A	Canon DR-2510C	A
Avision AD240	A	Canon DR-2580C	A
Avision AD250	B	Canon DR-3010C	A
Avision AD260	A	Canon P-150	A
Avision AD280	B	Canon P-215	A
Avision AV320/AV320+/AV320D2+	B	Canon DR-C120/F120	A
Avision AV3850SU	B	Canon DR-C125	A
Avision AV8350	D	Canon DR-C130	A
		Canon DR-C225/225W	A
<b>Bell &amp; Howell 2138</b>	D	Canon DR-C230/C240	A
Bell & Howell Truper 3200	D	Canon DR-M140	A
Bell & Howell Truper 3600	D	Canon DR-M160/M160II	B
Bell & Howell 730DC FB	C	Canon DR-M1060	C
Bell & Howell 8080D-B/S-B SCSI	E	Canon DR-M260	B
Bell & Howell 8080DB-I Spectrum	E	Canon DR-3020/DR-3060	B
Bell & Howell 8080SB/SC Spectrum	E	Canon DR-3080C/380CII	B
Bell & Howell 8090 Spectrum XF	E	Canon DR-4010C	B
Bell & Howell 8100 (SCSI and Spectrum)	E	Canon DR-4580U	C
Bell & Howell 8120 Spectrum XF	F	Canon DR-5010C	D
Bell & Howell 8125S/8125D SCSI / Video	F	Canon DR-5020	D
Bell & Howell 8125DB-I/DC-I Spectrum	F	Canon DR-5060F	D
Bell & Howell 8140 Spectrum XF	F	Canon DR-5080C	D
Bell & Howell Ngenuity 9090	E	Canon DR-6010C	B
Bell & Howell Ngenuity 9125	E	Canon DR-6030C/6050C	D
Bell & Howell Ngenuity 9150	F	Canon DR-6080C	D
Bell & Howell SideKick 1200	B	Canon DR-7080C/7090C	D
Bell & Howell SideKick 1400/1400u	B	Canon DR-7550C	DX
		Canon DR-7580	D
<b>Brother ADS-2000</b>	A	Canon DR-9050C/9080C	E
Brother ADS-2100	A	Canon DR-X10C (with and w/out VRS)	E
Brother ADS-2500W	A	Canon DR-G1100	DX
Brother ADS-2600W	A	Canon DR-G1130	E
		Canon DR-G2090	D
<b>Colortrac SmartLF/A0</b>	C	Canon DR-G2110	DX
		Canon DR-G2140	E
		Canon MS-300/MS-350/MS-800	C

Scanner Model	Group
<b>Contex XD2490</b>	<b>B</b>
Contex SD4410	C
Contex SD4430	C
Contex SD4450	C
Contex SD4490	C
<b>Fujitsu fi-4120C2</b>	<b>A</b>
Fujitsu fi-4220C/4220C2	A
Fujitsu fi-4340C	B
Fujitsu fi-4530C	C
Fujitsu fi-4750C/4750L	D
Fujitsu fi-4860C/4860C2	D
Fujitsu fi-5015C	A
Fujitsu fi-5110C	A
Fujitsu fi-5120C	A
Fujitsu fi-5220C	A
Fujitsu fi-5530C/5530C2	D
Fujitsu fi-5650C	D
Fujitsu fi-5750C	D
Fujitsu fi-5900C	E
Fujitsu fi-5950	E
Fujitsu fi-60F	A
Fujitsu fi-6110	A
Fujitsu fi-6130/6130Z	A
Fujitsu fi-6140/6140Z	B
Fujitsu fi-6230/6230Z	A
Fujitsu fi-6240/6240Z	B
Fujitsu fi-6400	DX
Fujitsu fi-6670/6670A VRS	DX
Fujitsu fi-6750	DX
Fujitsu fi-6770/6770A VRS	DX
Fujitsu fi-6800	E
Fujitsu fi-7030	A
Fujitsu fi-7140	A
Fujitsu fi-7160	B
Fujitsu fi-7180	B
Fujitsu fi-7240	A
Fujitsu fi-7260	B
Fujitsu fi-7280	B

Scanner Model	Group
Fujitsu fi-7460	C
Fujitsu fi-7480	D
Fujitsu fi-7600	DX
Fujitsu fi-7700	DX
Fujitsu fi-7800	DX
Fujitsu fi-7900	E
Fujitsu M4097D	D
Fujitsu M4099D	D
Fujitsu ScanPartner 620C	A
Fujitsu ScanPartner 93GX	A
Fujitsu SP-1120	A
Fujitsu SP-1125	A
Fujitsu SP-1130	A
<b>Epson GT 1500</b>	<b>A</b>
Epson GT-2500	A
Epson GT-S50	A
Epson GT-S55	A
Epson GT-S80	A
Epson GT-S85	A
Epson GT-20000	A
Epson GT-30000	C
Epson DS-510	A
Epson DS-530	A
Epson DS-760	A
Epson DS-770	A
Epson DS-860	B
Epson DS-50000	A
Epson DS-60000	B
Epson DS-70000	D

Scanner Model	Group
<b>Hewlett-Packard ScanJet Pro 3000 s2</b>	A
Hewlett-Packard ScanJet 4500	A
Hewlett-Packard ScanJet 5000	A
Hewlett-Packard ScanJet 5590	A
Hewlett-Packard ScanJet 7000	B
Hewlett-Packard ScanJet 7500	B
Hewlett-Packard ScanJet 7650	A
Hewlett-Packard ScanJet 7800	A
Hewlett-Packard ScanJet 8200c	A
Hewlett-Packard ScanJet 8250c	A
Hewlett-Packard ScanJet 8270	A
Hewlett-Packard ScanJet 8290c	A
Hewlett-Packard ScanJet 8350	A
Hewlett-Packard ScanJet 8390	B
Hewlett-Packard ScanJet 9000	D
Hewlett-Packard ScanJet N6350	A
Hewlett-Packard ScanJet N7710	B
Hewlett-Packard ScanJet N8420	A
Hewlett-Packard ScanJet N8460	B
Hewlett-Packard ScanJet N9120	D

Scanner Model	Group
<b>Hitachi HT-4139</b>	F
<b>IBML ImageTrac DS-1155</b>	G
IBML ImageTrac DS-1210	G
<b>InoTec Scamax 401/402/403 Series</b>	E
InoTec Scamax 411/412/413 Series	E
InoTec Scamax 421/422/423 Series	F
InoTec Scamax 433 Series	G
InoTec Scamax 510 Series	G
InoTec Scamax 515 Series	G

Scanner Model	Group
<b>Kodak DIGITAL SCIENCE 3500</b>	E
Kodak DIGITAL SCIENCE 3510	E
Kodak DIGITAL SCIENCE 3520D	E
Kodak i30	A
Kodak i40	A
Kodak i55	B
Kodak i65	B
Kodak i150	C
Kodak i160	C
Kodak i250	D
Kodak i260	D
Kodak i280	D
Kodak i610/i620	E
Kodak i640	E
Kodak i660	F
Kodak i730	E
Kodak i750	E
Kodak i780	F
Kodak i810/i820	F
Kodak i830/i840	G
Kodak i1210/i1220	A
Kodak i1310/i1320	B
Kodak i1405	B
Kodak i1410/i1420/i1440	D
Kodak Ngenuity 9090	E
Kodak Ngenuity 9125	E
Kodak Ngenuity 9150	F
Kodak PS50/PS80	A
Kodak PS410	A
Kodak PS810	B
Kodak SideKick 1200/1400u	B
Kodak Truper 3200/3210	D
Kodak Truper 3600/3610	D
Kodak Capture Pro Auto Import *	E

\* Auto Import functionality is also available in the **Capture Pro Software Auto Import Edition**. Please note that scanning is not supported in the Auto Import Edition.

Scanner Model	Group
<b>Kodak/Alaris E1025</b>	A
Kodak/Alaris E1035	A
Kodak/Alaris S2040	A
Kodak/Alaris S2050	A
Kodak/Alaris S2060w	A
Kodak/Alaris S2070	A
Kodak/Alaris S2080w	B
<b>Kodak SCANMATE i920/i940</b>	A
Kodak SCANMATE i1120	A
Kodak SCANMATE i1150/i1150WN	A
Kodak SCANMATE i1180	A
Kodak i1190/i1190e/i1190WN	A
Kodak i1840/i1860	G
Kodak i2400/i2420	A
Kodak i2600/i2620	A
Kodak i2800/i2820	B
Kodak i2900	B
Kodak i3200/i3250	C
Kodak i3300	C
Kodak i3400/i3450	D
Kodak i3500	D
Kodak i4200/i4200 Plus	DX
Kodak i4250	DX
Kodak i4600/i4600 Plus	E
Kodak i4650	E
Kodak i4850	E
Kodak i5200/i5200V	E
Kodak i5250/i5250V	E
Kodak i5600/i5600V	F
Kodak i5650/i5650V/i5650S	F
Kodak i5800/i5850/i5850S	G
Kodak S2085f	B
Kodak S3060/S3060f	C
Kodak S3080	C
Kodak S3090	C
Kodak S3100/S3100f	C
Kodak S3110	C
Kodak S3120	D
Kodak S3000P/S3000D/S3000S	C

Scanner Model	Group
<b>Microform XINOScan 713</b>	<b>E</b>
Microform XINOScan 716	F
Microform XINOScan 720	G
<b>Panasonic KV-S1015C</b>	<b>A</b>
Panasonic KV-S1020	A
Panasonic KV-S1025	A
Panasonic KV-S1026C	A
Panasonic KV-S1027	A
Panasonic KV-S1045C	A
Panasonic KV-S1046C	A
Panasonic KV-S1057	B
Panasonic KV-S1065C	B
Panasonic KV-S2026C	A
Panasonic KV-S2028C	A
Panasonic KV-S2045C	B
Panasonic KV-S2046C	B
Panasonic KV-S2048C	B
Panasonic KV-S2065L	D
Panasonic KV-S2065W	D
Panasonic KV-S2087	B
Panasonic KV-S3065 CL/CW	D
Panasonic KV-S3085	E
Panasonic KV-S3105C	F
Panasonic KV-S4065C CL/CW	DX
Panasonic KV-S4085C CL/CW	E
Panasonic KV-S5046H	D
Panasonic KV-5055C	D
Panasonic KV-5076H	DX
Panasonic KV-S6050W	D
Panasonic KV-S6055W	D
Panasonic KV-S7065C	D
Panasonic KV-S7075C	D
Panasonic KV-S7077	C
Panasonic KV-S7097	D
Panasonic KV-S8127	E
Panasonic KV-S8147	E

Scanner Model	Group
<b>Plustek PS406/PS406U</b>	<b>A</b>
Plustek PS406U Pro	A
<b>Ricoh IS 01</b>	<b>C</b>
Ricoh IS 330	C
Ricoh IS 410	C
Ricoh IS 420	C
Ricoh IS 430	D
Ricoh IS 450	D
Ricoh IS760/IS760D	D
<b>ScanOptics SO Series</b>	<b>G</b>
<b>Scantron iNSIGHT 20</b>	<b>A</b>
Scantron iNSIGHT 30	D
<b>Visioneer PT680 (same as Patriot 680)</b>	<b>B</b>
Visioneer PT780 (same as Patriot 780)	D
Visioneer Strobe XP450	A
Visioneer Strobe XP470	B
<b>Xerox Documate 250</b>	<b>A</b>
Xerox Documate 252	A
Xerox Documate 262 (also 262i)	B
Xerox Documate 272	B
Xerox Documate 3460	B
Xerox Documate 3640	B
Xerox Documate 4440	A
Xerox Documate 4760	D
Xerox Documate 4790	DX
Xerox Documate 4799	E
Xerox Documate 4830	C
Xerox Documate 5445	A
Xerox Documate 5460	B
Xerox Documate 6440	A
Xerox Documate 632 (also DM632)	B
Xerox Documate 752	D
Xerox Documate 765	D